

Micro

A

B

C











D

A

B

C

D





1

2


3

4


IO HEADERS




MICRO SD




BUTTONS




RTC




USB




WiFi



FLASH



POWER



LED

